



# ER - 230

# ER - 460



electric reefer solutions  
955 76th St., SW  
Byron Center, MI 49315  
888-696-2230  
[www.electricreefersolutions.com](http://www.electricreefersolutions.com)



# Table of Contents

- Introduction ..... 2
- Safety Precautions ..... 3
- Specification/Components ..... 4
- Unit Description ..... 5
- Maintenance Schedule ..... 6
- Operating Instructions ..... 7
- Warranty Policy ..... 8
  
- Parts List
  - ER 230 Volt ..... 9
  - ER 230 Narrow Post ..... 10
  - ER 460 Volt ..... 11
  
- Wiring Diagrams
  - 208-230 VAC ..... 12
  - 460/480 VAC ..... 13

## Introduction

The ER 230 / ER-460 is an all electric stationary refrigeration unit. It uses 3-phase power and R404A refrigerant for cooling and heating. The ER 230 / ER-460 is a remanufactured reefer with a new scroll compressor, fan motor, and controls. That results in a reliable, quiet, highly efficient, high capacity unit with low maintenance.

## Safety

Unit uses high voltage and high pressure refrigerant. The unit may start at any time without warning if turned on. Use caution around moving parts, electrical, and refrigeration components. Only qualified persons should perform maintenance and inspection of unit.

## Control

A solid state, totally programmable, control thermostat features separate and adjustable cool and heat set points and adjustable differentials for customizing temperature control. It also is able to display Fahrenheit or Celsius cargo temperature and has an internal "safety lock" switch to prevent tampering with settings.

## Defrost

Defrosting of the evaporator coil can be indicated in three ways: 1. Timer - clocks compressor run time. 2. Air differential switch. 3. Manual switch. Defrost is terminated by a temperature switch on the evaporator coil.

## Protection Devices

The scroll compressor has a phase detect module that will stop operation if the rotations is backwards (this is a common situation during initial installation/power up) and turn on the fault light. Compressor and fan motor each have overload switches for high amperage prevention. High and Low pressure switches protect the refrigeration system.

**Note!** Do not operate the scroll compressor in a deep vacuum during maintenance procedures. Compressor Damage will Result!

## Unit Identification

Serial Plate is located on unit frame below control switch

# Safety Precautions

## General Practices

1. ALWAYS WEAR GOGGLES OR SAFETY GLASSES. Refrigerant liquid can permanently damage the eyes.
2. Never operate the unit with the compressor discharge closed.
3. Keep your hands clear of the fans and belts when the unit is running.
4. Never apply heat to a sealed refrigeration system or container.
5. Fluorocarbon refrigerants, in the presence of an open flame or electrical short, produce toxic gases that are severe respiratory irritants capable of causing death.
6. Use caution when working around exposed coil fins. The fins can cause painful lacerations.
7. Use caution when working with a refrigerant or refrigeration system in any enclosed or confined area with a limited air supply (for example, a trailer, container, or in the hold of a ship). Refrigerant tends to displace air and can cause oxygen depletion which may result in death by suffocation.

Although fluorocarbon refrigerants are classified as safe refrigerants, certain precautions must be observed when handling them or servicing a unit in which they are used. When released to the atmosphere from the liquid state, fluorocarbon refrigerants evaporate rapidly, freezing anything they contact.

Avoid refrigeration oil contact with the eyes. Avoid prolonged or repeated contact of refrigeration oil with skin or clothing. Wash thoroughly after handling refrigeration oil to prevent irritation.

# Specifications/Components

Compressor	Copeland™ Scroll With Phase Detect. Phase Detect Module - 208-230 V.A.C. only Oil Capacity 140 oz. - Thermo King™ Part number 203-0514 ester oil. Liquid Injection*
Refrigerant	14 lbs-R404A
Fan Motor	2HP-208-230 V.A.C. RPMS -1735 Fan cooled. Totally enclosed Motor Rotation - Clockwise Facing Pulley
Defrost Timer	Clock-208-230 V.A.C. / 460-480 V.A.C Switch - 24 V.A.C. - Adjustable
Voltage	208-230 V.A.C. 3 Phase standard
Optional	460-480 V.A.C. 3 Phase Note: Units cannot be switched for high - low voltage
Control Voltage	24 V.A.C.
High Pressure Cut Out	Normally closed Opens at 470 PSI Reset at 375 PSI
Low Pressure Cut Out	Normally closed Opens at 5 to 11 in vacuum Resets at 4 to 7 psi
Suction Pressure Regulator	30 PSI
Defrost Air Switch	1.0 inches of water column
Supply Power Requirements	208-230 V.A.C. - 60 AMP 460 V.A.C.-30 AMP
Compressor and Fan Overload Protection	Manual Reset
Pilot Solenoid (3 way valve)	24 V.A.C.
Liquid Injection Solenoid	24 V.A.C.

## Unit Description

The ER 230 / ER-460 is a one piece, self contained, all electric, refrigeration unit. It heats and cools with R404A Refrigerant.

The ER 230 / ER-460 starts and stops automatically to maintain temperature in cargo area.

Temperature control is fully adjustable in cool, heat, and null cycles. -20 degrees to 90 degrees Fahrenheit. Temperature is selectable in Celsius or Fahrenheit.

Phase Detect Module Monitors Compressor rotation and prevents compressor operation if incorrect (phase fault light will come on, fan motor and compressor will not run).

Defrost can be initiated in 3 ways: Manual switch, Air Differential Switch, and Timer. Defrost is terminated by an evaporator temperature switch. Defrost can be initiated only if evaporator temperature is below 37 Deg. F. Defrost timer clocks compressor run time (not time of day).

Fan Motor turns off in defrost cycle to keep heat in evaporator coil and drip pan. Length of defrost cycle is determined by quantity of Ice/Frost on coil and cargo temperature.

Compressor and Fan overload switches work together to: Protect compressor and or fan from high amp situation. Prevent Compressor operation if fan is disabled.

Liquid injection operates whenever compressor is running.

Control Voltage is supplied by a step down transformer in control box.

Control wiring Logic and identification is similar to transport refrigeration units.

# Maintenance Schedule

## Bi-Monthly Inspection

- Adjust or Replace Fan Belt.
- Visually inspect condenser and evaporator coils for dirt or debris. Clean if necessary.
- Operate in cool for 10 minutes. The ball in the receiver tank sight glass should be floating at the top.
- Listen for unusual noises or vibrations etc.
- If Evaporator is below 35 deg. F (45 deg. F cargo) initiate manual defrost.
- The fan should stop and the defrost light comes on. Let defrost terminate.
- Check Compressor oil level. The oil should be visible in the sight glass. (while running).
- Check indicator lights: cool, defrost, heat, unit-on.
- Check for loose or broken items.
- Inspect Wiring for damage.

## 6 Month Inspection

- Do Bi-Monthly Inspection.
- Clean condenser coil.
- Clean/check defrost drain tubes.
- While Operating, check compressor and fan contactors for abnormal temperature with and infrared temperature gun.  
**\*CAUTION! High voltage is present.**  
Use proper Procedures! If abnormal, disconnect power to unit and tighten/repair connections.

## 1 Year Inspection

- Do 6 month inspection
- Check air switch operation and setting - 1.0.
- Install refrigeration service gauges and check operation in cool, heat, and defrost.
- Check suction pressure regulator setting - 30 psi.
- Inspect fan shaft for leakage or bearing noise.

**\*\*\* Note: do not operate scroll compressor in a deep vacuum!**

## Maintenance General

Use diagnosing and repair procedures common to transport refrigeration units. Only qualified persons should perform maintenance on this unit. Use caution around high voltage and moving parts.

# Operating Instructions

To operate the unit turn the on/off switch on, set temperature control thermostat to desired temperature. See decal on unit for proper procedure or refer to the same information following. Unit will operate to set point and cycle off. As the temperature drifts away from set point, the unit will restart (subject to programmed differential).

## ER 230 / ER-460 - ELECTRONIC TEMPERATURE CONTROL

WHEN THE SETPOINT NEEDS TO BE CHANGED, THE SETTING FOR HEAT AND FOR COOL BOTH NEED TO BE ADJUSTED. THESE TWO SETTINGS ARE CALLED- S1 (COOL) AND S2 (HEAT).

DO NOT CHANGE THE DIFFERENTIAL SETTING ON COOL OR HEAT (4- 6 DEG.).DO NOT CHANGE THE "STAGE" SETTING- C1 (COOL MODE) AND H2 (HEAT MODE). THE HEAT SET POINT (S2) SHOULD ALWAYS BE 2-3DEG. LOWER THAN THE COOL SET POINT (S1).

TO CHANGE THE SETPOINTS, SCROLL THRU THE SCREENS USING THE "SET" KEY AS SHOWN BELOW AND CHANGE ONLY THE S1 AND S2 SCREENS. NOTE; THERE IS NO "ENTER OR LOAD" BUTTON. MAKE THE CHANGE WITH THE UP OR DOWN KEY AND MOVE TO THE NEXT SCREEN OR STOP AND IT WILL ACCEPT THE CHANGE AND RETURN TO THE "BOX TEMP" SCREEN. THE SECOND SCREEN F/C IS FAHRENHEIT/ CELSIUS.

**Example;** setpoint of 38 degrees with warm ambient (outside temp)

Set S1 at 38 deg.

Set S2 at 35 deg.

Unit will cool to 38 deg. and shut off. As the temperature warms up in the trailer, the unit will restart when the cool differential is reached. (4-6 deg. above setpoint)

If it is a cold ambient, the unit will heat to 35 deg. and shut off. It will restart when the heat differential is reached. (4-6 deg. below heat setpoint)

BOX TEMP—F /C.—SI—DIF 1—CI—S2—DIP 2—H2—BACK TO BOX TEMP

^  
COOL S/P  
SELECT

^  
HEAT S/P  
SELECT

# ER 230 / ER-460 WARRANTY POLICY

## ONE YEAR WARRANTY ON PARTS FROM DATE OF SALE

1. Thermo King™ parts are reimbursed at 10% over dealer cost.
2. Compressor is warranted through the closest Copeland™ dealer.
3. Grainger™ parts are warranted through the closest Grainger™ dealer.
4. R404A will be reimbursed at a predetermined rate.
5. Electric Reefer Solutions must be advised in advance of repairs that will be invoiced to them. Call 1-888-696-2230 and ask for Dan in the service dept.
6. For parts that fail and were not “new” when the unit was assembled, Electric Reefer Solutions may supply a “good used” part for the repair.

## LABOR IS COVERED FOR 30 DAYS FROM DATE OF SALE

1. Labor will be reimbursed at a predetermined rate.
2. TK DAC flat rates are to be used for labor billing.
3. Travel time is not covered.

## SUMMARY

This is a reconditioned unit with a new compressor and new controls. Some outer body panels may not be new, but are repainted by a professional body shop. 3-way valve is rebuilt, coils are cleaned, and the frame is cleaned, painted, and treated for corrosion. The end user is to supply the a/c power connection to the control box (according to State and Local Code).

## Grainger™ Warranty Process:

Bring defective part to the local Grainger™ dealer. Identify the part number. Please give Grainger™ dealer Electric Reefer Solutions’s phone number (616-878-4900). Grainger™ dealer will confirm the history of sale and exchange the part at no charge for one year after the Electric Reefer Solutions’s unit invoice date.

### GENERAL WARRANTY

The Manufacturer generally warrants the goods to be free from defects in material and workmanship for a specified period from the date put in service. Such warranty is limited, at Manufacturer’s option, to repair or replacement at any authorized Manufacturer’s dealer of any part or parts that shall be determined to have failed within the specified period of warranty. Such repair or replacement shall be Buyer’s exclusive remedy and correction of defects in the above manner shall constitute complete fulfillment of all obligations and liabilities of Manufacturer with respect to the goods sold, whether based in contract, in tort, or otherwise. MANUFACTURER’S EXPRESS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

### GENERAL TERMS OF SALE

SELLER SHALL NOT BE LIABLE, IN CONTRACT OR IN TORT, FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS, INJURY OR DAMAGE CAUSED TO PERSONS, CONTAINERS, TRAILERS, CONTENTS OR PRODUCT CARGO BY REASON OF THE POSSESSION, USE, INSTALLATION, MODIFICATION, REPAIR, MAINTENANCE, OR MECHANICAL FAILURE OF ANY GOODS OR SERVICES.

**Indemnification:** Buyer agrees to indemnify and hold Seller, its agents, employees, successors and assigns harmless from and against any and all claims and causes of action brought against Seller and from any and all damages, losses, expenses, attorneys fees, costs and liabilities sustained by Seller arising out of Buyer’s possession or use of the goods or Buyer’s breach of the terms and conditions of this quotation. Risk of loss to the goods shall pass to Buyer upon delivery of the goods to Electric Reefer Solutions, regardless of whether freight charges are prepaid.

**Patents:** Buyer shall indemnify and hold Seller, its agents and employees, harmless from any claim or cause of action arising out of Seller’s infringement of a patent, copyright, trademark, trade name, or other proprietary right, or claim of unfair trade or of unfair competition, in connection with Buyer’s possession or use of the goods. Buyer also agrees not to infringe upon any patent rights of Manufacturer in connection with the goods and agrees not to contest Manufacturer’s patent rights nor the scope of those rights.

**Delay and Failure to Deliver:** Buyer acknowledges that any specified delivery date is only a good faith estimate of the actual delivery date. Seller shall not be liable in any respect for failure to ship or for delay in shipment where the failure or delay is due in whole or in part to an act of God, fire, action or delay of a governmental entity, shortage or curtailment of material, labor, transportation or utility services, or to any labor or production difficulty in Seller’s plant or those of its suppliers, or to any other cause beyond Seller’s control. In the event of a delay, the delivery date shall be postponed for a length of time as may be reasonably necessary to compensate for the delay.

**Buyer Acknowledgement of Hazards:** Buyer acknowledges that the goods may contain CFC-12 or CFC-115, are manufactured with methyl chloroform, which are Hazardous Substances as defined under relevant federal and state environmental laws, and may destroy ozone in the upper atmosphere. Buyer agrees to indemnify and hold Seller and its agents, employees harmless from all claims and liabilities relating to the use or release of these Hazardous Substances.

**Miscellaneous:** Buyer shall not assign its rights or delegate its duties under this quotation without Seller’s prior written consent. The contract evidenced by this quotation may be amended only in writing signed by Seller and Buyer. If any provision of this quotation is invalid or unenforceable, all other provisions of this quotation shall remain in full force and effect. The sale of goods and services in accordance with this quotation shall be governed in all respects by the laws of the State of Michigan. Seller and Buyer agree that any action arising out of the sale of goods or services in accordance with this quotation will be brought, heard and decided in Kent County, in the State of Michigan. The terms of this quotation shall inure to the benefit of and be binding on the successors and assigns of the parties. There are no other agreements, warranties, terms or conditions relating to the goods or services to be provided under this quotation.

**ER 230 VOLT**

<b>QTY</b>	<b>PART#</b>	<b>DESCRIPTION</b>
1	ER-22001	COMPRESSOR 230V
2	ER-44001	INDICATOR LIGHT RED
2	ER-44002	INDICATOR LIGHT GREEN
1	ER-44003	INDICATOR LIGHT AMBER
1	ER-44005	TIMER
1	ER-44006	CONTACTOR 9 AMP
1	ER-44007	CONTACTOR 25 AMP
1	ER-44010	OVERLOAD COMPRESSOR
1	ER-44012	OVERLOAD FAN
1	ER-44013	MOTOR
1	ER-44015	TEMPERATURE CONTROL
1	ER-44016	HPCO R404A
1	ER-44017	SWITCH DEFROST
1	ER-44018	SWITCH ON/OFF
1	ER-44019	SWITCH DEFROST TERMINATION
1	ER-44020	BREAKER
1	ER-44021	LPCO R404A
5	ER-44023	CONNECTOR ELECTRICAL BOX
2	ER-44024	RELAY
2	ER-44025	SOCKET RELAY
1	ER-44026	24V TRANSFORMER
1	ER-44027	MOUNTING TRACK ELECTRICAL BOX
1	ER-44028	TERMINAL STRIP
2	ER-44029	RESET SWITCH
2	ER-44030	COIL SOLENOID VALVE
1	ER-66001	ROTOLOCK VALVE 1-3/8" OD
1	ER-66002	ROTOLOCK VALVE 1-1/8 OD
1	ER-66003	OIL POLYOLESTER
1	ER-66004	KIT 3-WAY VALVE REBUILD
1	ER-66005	DRIER O-RING FACE SEAL
1	ER-66006	CAP 3-WAY VALVE
1	ER-66007	EXPANSION VALVE SOLDER/FLARE
1	ER-66008	DRIER FLARE 1/2"
1	ER-66009	DRIER FLARE 1/2"-5/8"
1	ER-66010	CHECK VALVE
1	ER-66011	RELIEF VALVE
1	ER-66012	EXPANSION VALVE SOLDER/SOLDER
1	ER-66013	CAP TUBE KIT
1	ER-66014	SUCTION PRESSURE REGULATOR
2	ER-66015	SOLENOID VALVE
1	ER-66016	REDUCER 1-1/8" X 3/4" COPPER
2	ER-66019	1-3/8" LONG RADIUS STREET ELBOW
1	ER-66022	SWITCH AIR
1	ER-66023	SUCTION FILTER
1	ER-66024	TANK RECEIVER
1	ER-77001	BUSHING ELECTRIC MOTOR
1	ER-77003	SHEAVE ELECTRIC MOTOR
1	ER-77006	BELT
1	ER-99001	NAMEPLATE COMPRESSOR OIL
4	ER-99002	LATCH DOOR
1	ER-99004	INT. PANEL
1	ER-99005	MOTOR MNTG.BASE
2	ER-99007	HINGE
1	ER-99009	NEMA ENCLOSURE
1	ER-99011	NAMEPLATE SWITCH
2	ER-99012	NAMEPLATE R404A
2	ER-99013	CROME GRILLE ROAD AND CURB SIDE
1	ER-99014	TOP CAP
1	ER-99015	FRONT HOOD
1	ER-99016	FRONT DOOR ROAD SIDE
1	ER-99017	FRONT DOOR CURBSIDE
1	ER-99018	PANEL CURBSIDE
1	ER-99019	PANEL ROADSIDE
1	ER-99020	CENTER BAND
1	ER-99021	CENTER ACCENT STRIP
1	ER-99022	DECAL ELECTRIC REEFER
1	ER-99023	DECAL ER-230
1	ER-99025	DECAL ZERO

**ER 230 NARROW POST**

<b>QTY</b>	<b>PART#</b>	<b>DESCRIPTION</b>
1	ER-22001	COMPRESSOR 230V
2	ER-44001	INDICATOR LIGHT RED
2	ER-44002	INDICATOR LIGHT GREEN
1	ER-44003	INDICATOR LIGHT AMBER
1	ER-44005	TIMER
1	ER-44006	CONTACTOR 9 AMP
1	ER-44007	CONTACTOR 25 AMP
1	ER-44008	OVERLOAD FAN
1	ER-44010	OVERLOAD COMPRESSOR
1	ER-44014	MOTOR
1	ER-44015	TEMPERATURE CONTROL
1	ER-44016	HPCO R404A
1	ER-44017	SWITCH DEFROST
1	ER-44018	SWITCH ON/OFF
1	ER-44019	SWITCH DEFROST TERMINATION
1	ER-44020	BREAKER
1	ER-44021	LPCO R404A
5	ER-44023	CONNECTOR ELECTRICAL BOX
2	ER-44024	RELAY
2	ER-44025	SOCKET RELAY
1	ER-44026	24V TRANSFORMER
1	ER-44027	MOUNTING TRACK ELECTRICAL BOX
1	ER-44028	TERMINAL STRIP
2	ER-44029	RESET SWITCH
2	ER-44030	COIL SOLENOID VALVE
1	ER-66001	ROTOLOCK VALVE 1-3/8" OD
1	ER-66002	ROTOLOCK VALVE 1-1/8" OD
1	ER-66003	OIL POLYOLESTER
1	ER-66004	KIT 3-WAY VALVE REBUILD
1	ER-66005	DRIER O-RING FACE SEAL
1	ER-66006	CAP 3-WAY VALVE
1	ER-66007	EXPANSION VALVE SOLDER/FLARE
1	ER-66008	DRIER FLARE 1/2"
1	ER-66009	DRIER FLARE 1/2"-5/8"
1	ER-66010	CHECK VALVE
1	ER-66011	RELIEF VALVE
1	ER-66012	EXPANSION VALVE SOLDER/SOLDER
1	ER-66013	CAP TUBE KIT
1	ER-66014	SUCTION PRESSURE REGULATOR
2	ER-66015	SOLENOID VALVE
1	ER-66016	REDUCER 1-1/8" X 3/4" COPPER
1	ER-66017	1-3/8" 45 DEGREE ELBOW
2	ER-66018	1-3/8" 45 STREET ELBOW
1	ER-66019	1-3/8" LONG RADIUS STREET ELBOW
1	ER-66020	3/4" 90 DEGREE ELBOW
1	ER-66021	3/4" LONG RADIUS 90 DEGREE STREET ELBOW
1	ER-66022	SWITCH AIR
1	ER-66023	SUCTION FILTER
1	ER-77002	BUSHING ELECTRIC MOTOR
1	ER-77004	SHEAVE ELECTRIC MOTOR
1	ER-77005	BELT
1	ER-99001	NAMEPLATE COMPRESSOR OIL
2	ER-99002	LATCH DOOR
1	ER-99003	INT. PANEL
1	ER-99006	MOTOR MNTG.BASE
1	ER-99008	NEMA ENCLOSURE
1	ER-99010	BRACKET DRIER
1	ER-99011	NAMEPLATE SWITCH
2	ER-99012	NAMEPLATE R404A
1	ER-99022	DECAL ELECTRIC REEFER

**ER 460 VOLT**

<b>QTY</b>	<b>PART#</b>	<b>DESCRIPTION</b>
1	ER-22002	COMPRESSOR 460V
2	ER-44001	INDICATOR LIGHT RED
2	ER-44002	INDICATOR LIGHT GREEN
1	ER-44003	INDICATOR LIGHT AMBER
1	ER-44004	TIMER
1	ER-44006	CONTACTOR 9 AMP
1	ER-44007	CONTACTOR 25 AMP
1	ER-44009	OVERLOAD COMPRESSOR
1	ER-44011	OVERLOAD FAN
1	ER-44013	MOTOR
1	ER-44015	TEMPERATURE CONTROL
1	ER-44016	HPCO R404A
1	ER-44017	SWITCH DEFROST
1	ER-44018	SWITCH ON/OFF
1	ER-44019	SWITCH DEFROST TERMINATION
1	ER-44020	BREAKER
1	ER-44021	LPCO R404A
1	ER-44022	TRANSFORMER 24V
5	ER-44023	CONNECTOR ELECTRICAL BOX
2	ER-44024	RELAY
2	ER-44025	SOCKET RELAY
1	ER-44027	MOUNTING TRACK ELECTRICAL BOX
1	ER-44028	TERMINAL STRIP
2	ER-44029	RESET SWITCH
2	ER-44030	COIL SOLENOID VALVE
1	ER-66001	ROTOLOCK VALVE 1-3/8" OD
1	ER-66002	ROTOLOCK VALVE 1-1/8 OD
1	ER-66003	OIL POLYOLESTER
1	ER-66004	KIT 3-WAY VALVE REBUILD
1	ER-66005	DRIER O-RING FACE SEAL
1	ER-66006	CAP 3-WAY VALVE
1	ER-66007	EXPANSION VALVE SOLDER/FLARE
1	ER-66008	DRIER FLARE 1/2"
1	ER-66009	DRIER FLARE 1/2"-5/8"
1	ER-66010	CHECK VALVE
1	ER-66011	RELIEF VALVE
1	ER-66012	EXPANSION VALVE SOLDER/SOLDER
1	ER-66013	CAP TUBE KIT
1	ER-66014	SUCTION PRESSURE REGULATOR
2	ER-66015	SOLENOID VALVE
1	ER-66016	REDUCER 1-1/8" X 3/4" COPPER
2	ER-66019	1-3/8" LONG RADIUS STREET ELBOW
1	ER-66022	SWITCH AIR
1	ER-66023	SUCTION FILTER
1	ER-66024	TANK RECEIVER
1	ER-77001	BUSHING ELECTRIC MOTOR
1	ER-77003	SHEAVE ELECTRIC MOTOR
1	ER-77006	BELT
1	ER-99001	NAMEPLATE COMPRESSOR OIL
4	ER-99002	LATCH DOOR
1	ER-99004	INT. PANEL
1	ER-99005	MOTOR MNTG.BASE
2	ER-99007	HINGE
1	ER-99009	NEMA ENCLOSURE
1	ER-99011	NAMEPLATE SWITCH
2	ER-99012	NAMEPLATE R404A
2	ER-99013	CROME GRILLE ROAD AND CURB SIDE
1	ER-99014	TOP CAP
1	ER-99015	FRONT HOOD
1	ER-99016	FRONT DOOR ROAD SIDE
1	ER-99017	FRONT DOOR CURBSIDE
1	ER-99018	PANEL CURBSIDE
1	ER-99019	PANEL ROADSIDE
1	ER-99020	CENTER BAND
1	ER-99021	CENTER ACCENT STRIP
1	ER-99022	DECAL ELECTRIC REEFER
1	ER-99024	DECAL ER-460
1	ER-99025	DECAL ZERO







**electric reefer solutions**

955 76th St., SW

Byron Center, MI 49315

888-696-2230

[www.electricreefersolutions.com](http://www.electricreefersolutions.com)